Tipps für die Nutzung deines Classic C-D6i

1. Entdecke neue Sender

   Tauche im Internetradio-Modus in eine Welt voller Genres und Sender ein, um deine nächsten Lieblingssongs zu entdecken.

2. Suche nach DAB-Sendern

   Bleib auf dem Laufenden! Öffne das DAB-Menü und starte einen Sendersuchlauf.

3. Du kannst deinen Sender auf DAB oder UKW nicht finden?

   Kein Problem! Verwende die Internetradio-Suche, um ihn ausfindig zu machen und speichere ihn für den einfachen Zugriff über die Favoriten-Schaltflächen oder die Favoritenliste.

4. Optimiere dein Hörerlebnis

   Wähle eines der 3 Equalizer-Profile aus, um den perfekten Klang zu erzielen, sei es für lebendige Dynamik, beruhigenden Komfort oder präzise Musikwiedergabe. Weitere Informationen findest du in Abschnitt 14.

5. Automatische Suche nach DAB- oder UKW-Sendern.

   Jedes Mal, wenn Sie einen automatischen Suchlauf nach DAB- oder UKW-Sendern durchführen, werden deine Radiofavoriten für diesen Modus gelöscht.
   Dies dient dazu, Duplizierungsfehler beim Scannen zu vermeiden.

   Bitte führe den automatischen Suchlauf bei vollständig ausgefahrener Antenne und an einem Ort mit gutem Empfang durch, um sicherzustellen, dass alle Sender gefunden werden.

   Sobald der Suchlauf abgeschlossen ist, füge die Sender erneut zu den Favoriten oder der Favoritenliste hinzu.

Fehlerbehebung

1. Es kommt kein Ton aus dem Lautsprecher
   - Achte darauf, dass die Lautstärke auf einen hörbaren Pegel eingestellt ist.
   - Überprüfe bei DAB- und UKW-Radiosendern die Signalstärkeanzeige – ein schlechtes Signal kann zu keinem Ton führen.
   - Wechsle zu einem anderen Sender oder einer anderen Quelle (z. B. Bluetooth oder Aux-Eingang), um festzustellen, ob das Problem mit dem aktuellen Sender zusammenhängt.
2. Das Radio verbindet sich nicht mit dem Wi-Fi oder bricht die Verbindung ab
   - Vergewissere dich, dass das Wi-Fi-Netzwerk aktiv ist und das Signal in der Nähe des Radios stark ist.
   - Starte deinen Router und dein Radio neu und verbinde dich dann wieder mit dem Netzwerk.
   - Vergewissere dich, dass dein Radio das richtige Wi-Fi-Passwort verwendet.
   - Prüfe, ob die Software/Firmware deines Radios aktuell ist.
   - Dieses Funkgerät unterstützt 2.4GHz. Bitte stelle sicher, dass der Router für 2.4GHz konfiguriert ist, nicht versteckt ist und eine gültige SSID sendet.
3. Bluetooth verbindet sich nicht oder trennt die Verbindung immer wieder
   - Vergewissere dich, dass Bluetooth auf deinem Gerät aktiviert ist und sich das Radio im Pairing-Modus befindet.
   - Entferne zuvor gekoppelte Geräte aus dem Radio oder aus den Bluetooth-Einstellungen deines Geräts und versuche es.
   - Starte sowohl das Radio als auch dein Gerät neu, bevor du die Verbindung erneut versuchst.

Symbols used on this product

	Description
⚠	Potentially serious risk to your personal safety. To avoid possible injury or death, obey all safety notices with this symbol.
⚠ 📖	Caution. Read the user manual before use.
⎓	DC voltage
⊖⊂⊕	DC connector polarity, the centre of the connector terminal is positive.
⏻	Where to switch on or off the product, or put it in standby.

1. Read all the safety information and instructions before using the product. When passing this product to someone, include all documents.
2. If you do not follow the operating instructions provided, it may compromise the safety of your product and this may invalidate the warranty.
3. Only use attachments / accessories specified by Pure for use with this product.
4. This product is intended for indoor use only. When in use ensure adequate ventilation and airflow around the product.
5. Do not expose the product to dripping or splashing. Do not place objects filled with liquids, such as vases, on the product. If liquid spills on to the product, switch it off at the mains immediately, disconnect the mains plug and contact your dealer. Never touch the plug or the product with wet hands.
6. Using the product in rooms or climates with high humidity and temperatures may cause condensation to form inside the product, which can damage the product. Use the product in moderate climates only.
7. Do not use your product in extremely hot or cold temperatures. Keep the product away from heat sources, such as radiators or gas/electric fires. Do not expose your product to naked flames, such as lighted candles.
8. Verify Line Voltage Before Use: Classic C-D6i has been designed for use with 100- 230 Vrms, 50/60 Hz AC current. Connection to a supply voltage other than that for which your product is intended can create a safety and fire hazard and may damage the unit. If you have any questions about the voltage requirements for your specific model or about the supply voltage in your area, contact your selling dealer before plugging the unit into a wall outlet.
9. Handle the Power Adapter with Care: When disconnecting the power adapter from an AC outlet, always pull the plug; never pull the cord. Install the product in a location where the power cable will not be trampled or pinched.
10. If you do not intend to use your speaker for any considerable length of time, disconnect the plug from the AC outlet. The products primary disconnect device is the mains plug and should be readily accessible.
11. Do Not Use Extension Cords: To avoid safety hazards, use only the power cord supplied with your unit. We do not recommend that extension cords be used with this product. As with all electrical devices, do not run power cords under rugs or carpets, or place heavy objects on them. Damaged power cords should be replaced immediately by an authorized service centre with a cord that meets factory specifications.
12. Do Not Open the Cabinet: There are no user-serviceable components inside this product. Opening the cabinet may present a shock hazard, and any modification to the product will void your warranty. If water accidentally falls inside the unit, disconnect it from the AC power source immediately
13. Dispose of the product in accordance with local environmental rules.
14. Disconnect your product from the power supply during lightning storms or if you will not use your product for a long period of time (for example, if you are going on holiday).
15. Always unplug your product from the AC power supply before cleaning. When cleaning the product, do not use any type of abrasive pad or abrasive cleaning solutions as these may damage the product's surface.
16. When exposed to electrostatic discharge, the device may malfunction. Reset the device to enable full recovery. If interference occurs, reorient or relocate the product. Increase the separation between devices causing and receiving interference.
17. Cease to use the product if there are any abnormalities during operation, such as high temperature, discolouration, bulging, leakage, and so on.
18. Medical device interference: The product contains a radio and other components that emit electromagnetic fields and magnets. These electromagnetic fields and magnets may interfere with pacemakers, defibrillators or other medical devices. Maintain a safe distance of separation between your medical device and the product. Consult your doctor and medical device manufacturer for information specific to your medical device. Stop using the product if you suspect it is interfering with your pacemaker, defibrillator or any other medical device.
19. Use only power adapter listed in these user manual/user instructions (supplied by Pure with model number: (RY45H150267) to power the equipment and do not use the power supply for any other purpose.
20. The direct plug-in adapter is used as a disconnect device, the disconnect device shall remain readily operable and accessible.

Approvals

CE marked. Hereby, Pure International Limited declares that this radio model Classic C-D6i is in compliance with the essential requirements of RED 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address:
https://www.pure-audio.com/policies/declaration-of-conformity

Pure International Limited declares that this radio model Classic C-D6i is in compliance with EN18031-1:2024 (No personal data used)

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG,Inc.and any use of such marks by Pure is under license. Other trademarks and trade names are those of their respective owners.

Warranty

Pure International Limited warrants to the end user that this product will be free from defects in materials and workmanship in the course of normal use for a period of two years from the date of purchase. This guarantee covers breakdowns due to manufacturing or design faults; it does not apply in cases such as accidental damage, however caused, wear and tear, negligence, adjustment, modification or repair not authorised by us.
Please visit www.pure-audio.com/register to register your product with us. Should you have a problem with your unit please contact your supplier or contact Pure Support at the address shown on the rear of this manual.